

Look for Phantom Loop

>LD 22
PT2000

REQ PRT
TYPE CEQU

CEQU
MPED 8D
SUPL 000 004 008 012
016 032 036 040
044 048 064 068
072 P096 ← This one already exists
XCT 000
CONF 029 030 031

DLOP NUM DCH FRM LCMT YALM T1TE TRSH
PRI 01 24 ESF B8S FDL 0 00
02 24 ESF B8S FDL 0 00
03 24 ESF B8S FDL 0 00
MISP

REQ *****

Build Phantom Loop

>LD 97
SCSYS000

REQ CHG
TYPE SUPL
SUPL N96
WRAP UP SUPL 096 (NEW) ..OK

REQ *****

Add Phantom TN

>LD 10

REQ: NEW
TYPE: 500
TN 61 0 ← Note that you use 61 to build TNs
PHANTOM
CDEN
DES TEST
CUST 0
DN *****
END OF EXAMPLE