

CS1000 KEY Choices

KEY	Description
AAG	ACD Answer Agent
AAK	Automatic Answerback
ACD	ACD Incoming Calls (In-Calls)
ACNT	ACD Activity Code Entry
ADL	Autodial
AGT	ACD Agent Status
AMG	ACD Answer Emergency Call
AO3	Three-Party Conference
AO6	Six-Party Conference
ARC	Attendant Recall
ASP	ACD Supervisor Call
ATW	ACD Call Waiting Time Indication
AWC	ACD Calls Waiting
BFS	Busy Forward Status
CA	Combined No Hold Conference And Autodial
CAS	Centralized Attendant Service
CFW	Call Forward All Calls
CH D	Combined No Hold Conference And Direct Hotline
CH L	Combined No Hold Conference And Hotline List
CHG	Charge Account
CLT	Configure Callers List
COS	Controlled Class Of Service
CPN	Calling Party Number
CS	Combined No Hold Conference And Speed Call
CSD	Conferee Selectable Display
CWT	Call Waiting
DAG	Display ACD Agents
DIG	Dial Intercom Group
DPU	Directed Call Pickup
DRC	Did Route Control
DSP	Display Key
DWC	ACD Display Calls Waiting
EMR	ACD Emergency
ENI	ACD Enable Interflow
EOVR	Enhanced Override
FDIS	Force Disconnect
FLH	DSN Flash Key
FOV	DSN Flash Override Key
GHD	Group Hunt Deactivation
GPU	Group Call Pickup
GRC	Group Call
HLD	Hold
HNDO	Hand-Off For A Mobile Extension User.
HOT D	Enhanced Hotline
HOT I	Hot Intercom
HOT L	One-Way Hotline
HOT P	HOT To PCA DN
ICF	Internal Call Forward
IMM	DSN Immediate Key (Autovon)
LNG	M2317 Language Toggle

KEY	Description
LNK	Last Number Redial
LSPK	Loudspeaker (SPEKABUS)
MCK	Message Cancellation
MCN	Multiple Call Non-Ringing Dn
MCR	Multiple Call Ringing Dn
MIK	Message Indication
MRK	Message Registration
MSB	Make Set Busy
MWK	Message Waiting
NHC	No Hold Conference
NRD	ACD Not Ready
NSVC	ACD Night Service
NUL	Removes Feature From Key
OBV	ACD Observe Agent
OSN	ESA/E911 On-Site Notification
OVB	ACD Overflow Position Busy
OVR	Override Key
PONW	Priority Override Network Wide
PRK	Call Park
PRS	Privacy Release
PRY	Priority Key (Autovon)
PVN	Private Line Non-Ringing Dn
PVR	Private Line Ringing Dn
RAG	ACD Ring Agent
RCK	Ringing Change Key
RDL	Redial Stored Number
RGA	Ring Again
RLS	Release
RLT	Configure Redial List
RMK	Room Status Key
RMWK	Remote Message Waiting Indication
RNP	Ringing Number Pickup
RPAG	Radio Paging
SCC	Speed Call Controller
SCN	Single Call Non-Ringing Dn
SCR	Single Call Ringing Dn
SCU	Speed Call User
SIG	Signal Key
SSC	System Speed Call Controller
SSU	System Speed Call User
THF	Centrex Trunk Switch Hook Flash
TRC	Malicious Call
TRN	Call Transfer
USR	User Selectable Call Redirection
UST	User Status
VCC	Voice Call
VDN	Volume Down
VUP	Volume Up
WUK	Guest Entry Of Automatic Wakeup
XMWK	Extended Message Waiting Indication